

Technical Tip

Doc Number: FT-8022

Date: 05/31/12

CM Version: CM6 v7.06+

Steps to Set a DAS with a 1BAM Remote

Below are the steps to setting up a DAS with a 1BAM remote.

1. Control Module Options

- 1) On the CM 6000, 6200 and 6300 turn 4-12 to 2.

2. DAS Programming

- 1) Key on and Door open
- 2) 0.5sec press 3 times on the remote; each time after the LED go out on the remote
- 3) After the LED goes out on the third press; 2.5 sec press and hold 1 time until you see the parking lights on the car flash two times. You have not entered DAS programming mode.
- 4) For stage 1; 0.5 sec press 1 time; then you will see the parking lights flash once. Close the car door and now strike the car to set stage 1 on the shock. After the strike it will chirp 1-10 to tell what it is set at. 10 being the hardest strike and 1 softest strike. It will per set stage 2 three levels higher then stage 1.
- 5) For stage 2; 2.5 sec press and hold 1 time. Then you will see the parking lights flash twice. Close the car door and now strike the car to set stage 2 on the shock. After the strike it will chirp 1-10 to tell what it is set at. 10 being the hardest strike and 1 softest strike.
- 6) 5 sec after stage 1 or 2 have been set you will get one parking light flash; it has now exited DAS programming.