



CAN HIGH + CAN LOW Connector Information



The DroneMobile X1MAX-LTE now includes a CAN-High and CAN-Low Harness for pulling vehicle health from the vehicle's OBD port.

HOW IT WORKS

While connected to a compatible Firstech or iData-link Remote Starter or Alarm, insert the CAN High/Low Connector (brown/white) into the 10-pin input on the X1 module. Hardwire the brown and white wires to the vehicle's OBD port.



BROWN - CAN High
WHITE - CAN Low

OPTIONAL ACCESSORIES

FT-HRN-X1-OBD

For standalone GPS tracking systems, pair the X1MAX-LTE with the X1-OBD Hardwire Harness. Available features:

- 12V Constant/Ground
- Ignition
- Up to 3 Programmable Outputs
- 1 Programmable Input
- OBD T-Harness (CAN High/Low)

